

Based on GPS-GSM Technology

The Ultimate Multi Layer

Vehicle Theft Protection

& Tracking System

For the first time in India

Geo Lock & Immobilize your Vehicle by Simply sending a SMS or through an Android Application.



Theft Protection:

- On sending a one touch message from your phone, locks the Vehicle in a particular geographical area, where it is being parked.
- Activates a hooter alarm if the vehicle crosses the locked geographical area.
- Sends an alert SMS to the vehicle owner upon Geo Lock Violation.
- ****Immobilizes the Vehicle upon Geo Lock Violation.

Locate Vehicle:

Send a SMS to the SIM connection in the device and get a SMS on your Phone about the location coordinates of the Vehicle. The location coordinates will provide the exact location of the vehicle on live maps.

Immobilize Vehicle:

****Immobilizes the vehicle upon sending a message. (This option can be used when the vehicle is in unauthorised motion)

No GPRS Connectivity required; No Recurring Charges
An active SIM connection with outgoing and incoming SMS facility should be inserted in the tracking device that is fitted in the vehicle.

Pl. Note:

- The hardware kit consists of a GPS Based Tracking Device, Immobilizer and a Hooter alongwith a loaded Vehicle Theft Protection Software.
- An active SIM connection is required to be inserted in the tracking device fitted in the vehicle, with Incoming and Outgoing SMS facility.
- ** Will not work if the vehicle is outside the GSM network.
- *** Live/On demand Tracking Facility is available at an additional cost on subscription of applicable Monthly Packages.
- **** Vehicle Immobilizer either Stops the vehicle immediately on receiving the message or prevents restarting the vehicle once it is Switched Off.(Depends on the electrical design of the Vehicle)

*conditions apply

Design
Development
Manufacturing
& Software
Services

For more information:
Contact: +91 9739221001
or write to us at:
sales@itriangle.in

An ISO 9001:2008 Certified Company

